



EIFS - WALL PENETRATION (METHOD 1)

- SEAL ALL **DUPONT™ TYVEK®** SEAMS AND REPAIR MINOR HOLES WITH **DUPONT™ TYVEK®** TAPE.
- FASTEN **DUPONT™ TYVEK®** WITH APPROVED FASTENERS AND SPACING.
- INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
- LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN ABOVE.



Tyvek.