



- NOTE**
- 1) SEAL ALL DUPONT™ TYVEK® WEATHER BARRIER SEAMS AND REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.
 - 2) FASTEN DUPONT™ TYVEK® WEATHER BARRIER WITH RECOMMENDED FASTENERS AND SPACING.
 - 3) INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
 - 4) THIS INFORMATION IS PROVIDED BY DUPONT AS REFERENCE ONLY; PLEASE CONSULT LOCAL BUILDING CODES, REGULATIONS AND LAWS TO DETERMINE THE APPROPRIATE CONSTRUCTION METHODS AND MATERIALS NEEDED.

SCALE: NOT TO SCALE
 REVISION DATE: 11/17/10
 DRAWING: CW-BXU-204

PARAPET WALL DETAIL

BRICK VENEER / EXTERIOR INSULATION (WRAP UNDER) / STEEL STUD WALL

