



**NOTE**  
 1) SEAL ALL DUPONT™ TYVEK® WEATHER BARRIER SEAMS AND REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.  
 2) FASTEN DUPONT™ TYVEK® WEATHER BARRIER WITH RECOMMENDED FASTENERS AND SPACING.  
 3) INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.  
 4) THIS INFORMATION IS PROVIDED BY DUPONT AS REFERENCE ONLY; PLEASE CONSULT LOCAL BUILDING CODES,  
 REGULATIONS AND LAWS TO DETERMINE THE APPROPRIATE CONSTRUCTION METHODS AND MATERIALS NEEDED.

SCALE: NOT TO SCALE  
 REVISION DATE: 11/17/10  
 DRAWING: CW-EIFS-200

**FLUID APPLIED TO WRAP TRANSITION**  
 EIFS / BRICK VENEER / STEEL STUD WALL

