



BUILDING SHEATHING - SEE DRAWINGS BY OTHERS

CEMENT PLASTER

METAL LATH

WALL MOUNTED SIGN/LETTER

PRE-DRILL HOLES AND FILL WITH COMPATIBLE SEALANT JUST PRIOR TO FASTENER INSTALLATION

SPECIFIED FASTENER

WOOD BLOCKING

DUPONT™ FLASHING TAPE OR DUPONT™ STRAIGHTFLASH™ SELF-ADHERED MEMBRANE TARGET PATCH EXTEND MIN. 4" PAST PENETRATIONS

INTERVENING LAYER

DUPONT™ TYVEK® WRB

NOTES:

1. SEALANT MUST BE COMPATIBLE AND APPROVED BY DUPONT™
2. INTERVENING LAYER CAN BE SECOND LAYER OF DUPONT™ TYVEK® WRB, A LAYER OF GRADE D BUILDING PAPER, FELT, RIGID FOAM BOARD OR THE BACKING OF PAPER-BACKED LATH.
3. REPAIR MINOR HOLES WITH DUPONT™ TYVEK® TAPE.
4. FASTEN DUPONT™ TYVEK® WRB WITH APPROVED FASTENERS AND SPACING.
5. INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.
6. LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERN OVER MATERIAL SELECTION AND DETAILING SHOWN.
7. FOR ADDITIONAL INFORMATION REGARDING PRODUCT INSTALLATION, REFER TO THE APPLICABLE DUPONT™ INSTALLATION GUIDELINE.



SCALE: NOT TO SCALE
 REVISION DATE: 11/1/16
 DRAWING: R-CP-1402-MA

SIGN PENETRATION
 CEMENT PLASTER