

NOTE

1) INTERIOR VAPOR RETARDER MAY BE REQUIRED IN SOME REGIONS.

2) THIS INFORMATION IS PROVIDED BY DUPONT AS REFERENCE ONLY; PLEASE CONSULT LOCAL BUILDING CODES, REGULATIONS AND LAWS TO DETERMINE THE APPROPRIATE CONSTRUCTION METHODS AND MATERIALS NEEDED.



SCALE: NOT TO SCALE

REVISION DATE: 4/28/10

DRAWING: FA-BX-W203s

FLANGED WINDOW SILL - METHOD 2
BRICK VENEER / EXTERIOR INSULATION / STEEL STUD WALL / SELF-ADHERED FLASHING

Tyvek.
FLUID APPLIED WB