



NOTE: FOR ADDITIONAL INFORMATION REGARDING PRODUCT INSTALLATION AND/OR FABRICATION INSTRUCTIONS FOR RECESSED WINDOW CORNERS, REFER TO THE APPLICABLE DUPONT™ SELF-ADHERED FLASHING SYSTEMS PRODUCTS INSTALLATION GUIDELINE.

Integral Flanged Door Before WRB Installation Sequence

DRAWING:
R-OP-3120-MA

REVISION DATE:
11/1/2016
SCALE: Not to Scale

