

## DuPont™ Elvax® 3165VLGA

### Elvax® resins Product Data Sheet

#### Description

Product Description	DuPont™ Elvax® 3165VLGA is an extrudable ethylene-vinyl acetate copolymer resin containing very low gel material available in pellet form for use in conventional extrusion equipment designed to process polyethylene resins.
---------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

#### Restrictions

Material Status	<ul style="list-style-type: none"> <li>Commercial: Active</li> </ul>
Availability	<ul style="list-style-type: none"> <li>Europe, Middle East</li> </ul>

#### Typical Characteristics

Composition	18 % By Weight Vinyl Acetate comonomer content Thermal Stabilizer: BHT antioxidant
Features	Very Low Gel
Applications	This resin is designed to provide a low temperature heat seal to itself or many other materials commonly used in flexible packaging applications. The melt properties of this resin allow it to be processed on blown film equipment over a wide range of film thickness and blow-up ratios. It can also be co-extruded with a variety of other polymers. This resin is typically used as low temperature seal layer in co-extruded films.

#### Typical Properties

Physical	Nominal Values	Test Method(s)	
* Density ( )	0.94 g/cm <sup>3</sup>	ASTM D792	ISO 1183
* Melt Flow Rate (190°C/2.16kg)	0.7 g/10 min	ASTM D1238	ISO 1133
Thermal	Nominal Values	Test Method(s)	
* Melting Point (DSC)	89°C (192°F)	ASTM D3418	ISO 3146
Freezing Point (DSC)	68°C (154°F)	ASTM D3418	ISO 3146
Vicat Softening Point ( )	69°C (156°F)	ASTM D1525	ISO 306

#### Processing Information

##### General

* Maximum Processing Temperature	230°C (446°F)
General Processing Information	Resin melt temperature should be maintained in the range of 150-175°C (300-350°F) to provide a suitable viscosity and melt strength for blown film extrusion. Higher temperatures may be more appropriate for co-extrusion with other

grades. Selection of a specific melt temperature will depend on considerations such as desired gauge, height of tower, cooling capacity, extruder hold up time, winding conditions, and other machine variables.

Elvax® can be used in conventional extrusion equipment designed to process polyethylene resins. However, corrosion-protected barrels, screws, adapters, and dies are recommended, since, at sustained melt temperatures above 446°F (230°C), ethylene vinyl acetate (EVA) resins may thermally degrade and release corrosive by-products.

#### **FDA Status Information**

ELVAX® 3165VLGA EVA Resin complies with Food and Drug Administration Regulation 21 CFR 177.1350(a)(1) - - Ethylene-vinyl acetate copolymers, subject to the limitations and requirements therein. This Regulation describes polymers that may be used in contact with food, subject to the finished food-contact article meeting the extractive limitations under the intended conditions of use, as shown in paragraph (b)(1) of the Regulation.

The information and certifications provided herein are based on data we believe to be reliable, to the best of our knowledge. The information and certifications apply only to the specific material designated herein as sold by DuPont and do not apply to use in any process or in combination with any other material. They are provided at the request of and without charge to our customers. Accordingly, DuPont cannot guarantee or warrant such certifications or information and assumes no liability for their use.

#### **Safety & Handling**

For information on appropriate Handling & Storage of this polymeric resin, please refer to the Material Safety Data Sheet..

A Product Safety Bulletin, Material Safety Data Sheet, and/or more detailed information on extrusion processing and/or compounding of this polymeric resin for specific applications are available from your DuPont Packaging and Industrial Polymers representative.

### **Read and Understand the Material Safety Data Sheet (MSDS) before using this product**

#### **Regional Centres**

DuPont operates in more than 70 countries. For help finding a local representative, please contact one of the following regional customer contact centers:

##### **Americas**

DuPont Company  
Chestnut Run Plaza – Bldg. 730  
974 Centre Road  
Wilmington, Delaware  
19805 U.S.A.  
Toll-Free (USA): 1-800-628-6208  
Telephone: 1-302-774-1000  
Fax: 1-302-355-4013

##### **Asia Pacific**

DuPont China Holding Co., Ltd.  
Shanghai Branch  
399 Keyuan Road, Bldg. 11  
Zhangjiang Hi-Tech Park  
Pudong New District, Shanghai  
P.R. China (Postcode: 201203)  
Telephone +86 21 3862 2888  
Fax +86-21-3862-2889

##### **Europe / Middle East / Africa**

DuPont de Nemours Int'l. S.A.  
2,Chemin du Pavillon Box 50  
CH-1218 Le Grand Saconnex  
Geneva, Switzerland  
Telephone +41 22 717 51 11  
Fax +41 22 717 55 00

DuPont do Brasil, S.A.  
Alameda Itapecuru, 506  
06454-080 Barueri, SP Brasil  
Telephone: +55 11 4166 8000  
Fax: +55 11 4166 8736

<http://elvax.dupont.com>

*The data listed here fall within the normal range of properties, but they should not be used to establish specification limits nor used alone as the basis of design. The DuPont Company assumes no obligations or liability for any advice furnished or for any results obtained with respect to this information. All such advice is given and accepted at the buyer's risk. The disclosure of information herein is not a licence to operate under, or a recommendation to infringe, any patent of DuPont or others. Since DuPont cannot anticipate all variations in actual end-use conditions, DuPont makes no warranties and assumes no liability in connection with any use of this information.*

*CAUTION: Do not use DuPont materials in medical applications involving implantations in the human body or contact with internal body fluids or tissues unless the material has been provided from DuPont under a written contract that is consistent with DuPont policy regarding medical applications and expressly acknowledges the contemplated use. For further information, please contact your DuPont representative. You may also request a copy of DuPont POLICY Regarding Medical Applications H-50103-3 and DuPont CAUTION Regarding Medical Applications H-50102-3.*

*Copyright © 2009 DuPont. The DuPont Oval Logo, DuPont™, The miracles of science™, and trademarks designated with "®" are registered trademarks or trademarks of E.I. du Pont de Nemours and Company or its affiliates. All rights reserved.*

*This data sheet is effective as of 06/29/2010 05:16:07 AM and supersedes all previous versions.*