

## GENERAL NOTES

- \*SEAL ALL TYVEK® JOINTS AND PENETRATIONS WITH APPROVED TAPE. (ex. DUPONT™ CONTRACTOR TAPE)
- \*FASTEN TYVEK® TO SHEATHING WITH LARGE HEAD NAILS OR USE NAILS WITH LARGE PLASTIC WASHER HEADS. (ex. DUPONT™ WRAPCAPS)
- \*SEAL OR GASKET BRICK TIES AT THE FACE OF TYVEK®
- \*LOCAL LAWS, ZONING, AND BUILDING CODES VARY AND THEREFORE GOVERNS OVER MATERIAL SELECTION AND DETAILING SHOWN BELOW.

### CANTILEVERED FLOOR

METAL SOFFIT

TYVEK® HOMEWRAP®

7/16" OSB SHEATHING

WOOD JOISTS

w/ R28 BATT INSULATION (MINIMUM)

5/8" TONGUE & GROOVE

PLYWOOD SUB-FLOOR

### TYPICAL WALL

MASONRY VENEER

1" AIR SPACE

TYVEK® HOMEWRAP®

7/16" OSB SHEATHING

2"x6" WOOD STUDS

w/ R-19 BATT INSULATION

VAPOR RETARDER

1/2" GYPSUM BOARD

CAULK TYVEK® (FROM WALL)  
TO TYVEK® (FROM CANTILEVER)


LAP 6" & TAPE/CAULK TYVEK® OVER  
THROUGH-WALL FLASHING

METAL ANGLE  
DESIGNED TO SUPPORT  
MASONRY WALL ABOVE

LAP AND TAPE TYVEK®  
AT JOINTS (UPPER SHEET  
OVER LOWER SHEET)

TYPICAL WALL

STAPLE VAPOR RETARDER  
BETWEEN JOISTS &  
TO U/S OF SUBFLOOR



## CANTILEVERED FLOOR DETAIL

RESIDENTIAL WOOD FRAME STRUCTURE w/ MASONRY VENEER

(HEATING CLIMATE)